

Installing PCI 7200 card drivers on Windows Vista

- 1. The first thing you need to do is turn off the UAC (User Account Control). You do this by going to the control panel, go to user accounts, and then locate the link for "User Account Control". You will need to make sure this feature is turned OFF. Then restart your computer.**
- 2. If you have already installed WinCnc 2.3.xx or previous versions on the computer you must run the "uninstdrv.bat" file found in the included PCI7200 folder. This will uninstall the previous PCI7200 device driver. Even if this is your first installation, running the unistdrv.bat will not hurt.**
- 3. Next, run the "instdrv.bat" file found in the included PCI7200 folder. This will install the new PCI7200 driver.**
- 4. Reboot your PC and you are ready to run WinCnc.**