

Phone: (304) 472 7206 Fax: (304) 472 9638

Installing PCI 7200 card drivers on Windows XP

1. Make sure you are running on a user account as Administrator. You can check this by clicking the “Start” button, clicking on “Control Panel”, then double clicking “User Accounts”. If it does not say “Computer Administrator” under the account you are logged in on, then you need to change it by clicking on that account, then click “Change My Account Type”.
2. If you have already installed WinCnc 2.3.xx or previous versions on the computer you must run the “uninstdrv.bat” file found in the included PCI7200 folder. This will uninstall the previous PCI7200 device driver. Even if this is your first installation, running the unistdrv.bat will not hurt.
3. Next, run the “instdrv.bat” file found in the included PCI7200 folder. This will install the new PCI7200 driver.
4. Reboot your PC and you are ready to run WinCnc.